封底

GIANT UK

GIANT UK

CPSC
MANUFACTURED:
MODEL NO.:
MANUFACTURED IN:

封面

GIANT UK

MOTOR HELMET
SPORTS HELMET

All patents and trademarks are the property of their respective owners. Giant and Liv hereby acknowledge such ownership.

135

ENGLISH

WARNING
Helmet has a limited lifespan in use and should be replaced if damaged. Do not use helmet if you buy this helmet a those children, adjusted properly, and worn properly. A cannot protect against all possible impacts. Follow all instructions in the manual completely. Failure to do so could result in serious injury or death.

LIMITED IMPACT PROTECTION
Giant and Liv helmets are designed to protect against all possible impacts. The helmet is designed to absorb shock by partial destruction of the shell and liner. This damage may not be visible. If the helmet is involved in an impact below, the helmet should be removed and replaced even if it appears undamaged. Helmet worn correctly, can cause serious injury or death. Energy absorbing can crush on impact. Subsequent impacts, some of the material compressed by the head. In addition, great enough it can result in serious injury or death. Because the variables in every accident are different, it is impossible to predict how or when the might occur.

WARNING!
Giant and Liv helmets are designed to be used by riders when participating in normal bicycling activities. They are not designed to help protect in other activities such as: motor vehicle use, equestrian activities, skateboarding, motorcycling, or high speed sports such as motorcycle racing, car racing, etc.

ENGLISH

1. Open the adjustor cam buckles (**Figure 3**).
2. Put the helmet on and slide the straps through the adjustor cam buckles. Position them in the correct position as indicated in Figures above.
3. Make sure there is no extra slack in any of the straps. Close the buckles to form the correct position.
4. Close and lock the adjustors.



ADJUSTING THE CHINSTRAP
The helmet is shipped with the chinstrap buckle under the lower left strap. Take the chinstrap buckle and pull the strap pulled tight. Make sure the chinstrap is NOT twisted and NOT on the front of the chin or mouth. Straps worn on the front of the chin can cause severe injury in a fall. Adjust the chinstrap so that it is snug but comfortable. **Figure 5** shows how to adjust the buckle and **Figure 6** shows proper placement of the chinstrap.



WARNING
Make sure the loose end of the strap is tucked through the keeper (**Figure 7**). If it does not, the strap may slide loose and the helmet could slip off during an accident.

ENGLISH

WARNING
HELMET FITTING
Your helmet should be sized to fit and be worn correctly to provide the greatest protection. Read and follow these instructions to properly fit your helmet and retention system. Grasp the helmet and try to rotate it forward and backward on your head. The helmet is comfortable and should not move forward to obscure vision or downward to expose the forehead. Unless this is the case, the helmet will not provide the best protection possible. Follow these Five Simple steps to ensure that you have the proper helmet size and have it worn it correct.

REMOVING/SIZING THE PADS
Always wear a helmet size in the front to protect your head. See **Figure 1** below for the proper way to fit a helmet.

IMPORTANT: All fitting adjustments MUST be made with the helmet positioned squarely on the head. Failure to do so will result in a poor fit and may allow the helmet to move out of position, during an accident.

FIGURE 1



CORRECT INCORRECT

LEARN THE MODIFIED V-RULE
THE STRAPS SHOULD FORM A "V" SHAPE UNDER EACH EAR WITH THE APEX OF THE V JUST BELOW AND SLIGHTLY IN FRONT OF THE EARS. SEE **FIGURE 2** FOR CORRECT POSITION.

ENGLISH

ALERTES CONCERNANT LA SÉCURITÉ
ALERTES CONCERNANT VOTRE CASQUE
Votre casque n'offre pas une protection illimitée dans le temps. Remplacez votre casque s'il a été endommagé (même légèrement) ou s'il a été impliqué dans un accident. Ne modifiez pas votre casque et ne retirez pas les étiquettes ou les garnitures de votre casque. Ne peignez pas votre casque.

ALERTES CONCERNANT VOTRE ENFANT/VOS ENFANTS
Seuls les adultes doivent régler le casque de leur enfant/leurs enfants. Votre enfant/vos enfants doivent porter un casque à chaque fois qu'ils font du vélo, de la trottinette, du roller, du skateboard ou toute autre activité de roulage.

ALERTES CONCERNANT LE PORT DU CASQUE
Votre casque doit être porté correctement pour offrir une protection optimale. Le casque doit être bien ajusté et ne doit pas bouger sur la tête. Il ne doit pas être trop serré ou trop lâche. Il ne doit pas gêner la vision périphérique. Il ne doit pas tomber sur les yeux ou sur le front. Il ne doit pas être incliné vers l'arrière. Il ne doit pas être trop haut sur la tête. Il ne doit pas être trop bas sur la tête. Il ne doit pas être trop serré sur le menton. Il ne doit pas être trop lâche sur le menton. Il ne doit pas être trop serré sur la mâchoire. Il ne doit pas être trop lâche sur la mâchoire. Il ne doit pas être trop serré sur le nez. Il ne doit pas être trop lâche sur le nez. Il ne doit pas être trop serré sur les oreilles. Il ne doit pas être trop lâche sur les oreilles. Il ne doit pas être trop serré sur la tête. Il ne doit pas être trop lâche sur la tête. Il ne doit pas être trop serré sur le cou. Il ne doit pas être trop lâche sur le cou