

GIANT

ridesync



RideSense (G-sensor)

ANDROID

IOS





ridesync



EN

- Manual -

JP

- マニュアル -

简体中文

- 操作手冊 -

繁體中文

- 操作手冊 -



GIANT

ridesync



HOW TO PAIR SENSOR

ALARM SYSTEM

ACCIDENT SYSTEM

Please download & install **Giant RideSync App** to your smartphone.







HOW TO PAIR SENSOR

RIDESYNC ARS

- Manual -

HOW TO PAIR SENSOR





RIDESYNC ARS

- Manual -


HOW TO PAIR SENSOR

0B/s
0B/s

3G 11:00

< Add Bike OK


Bike Data


 GIANT TCR

Edit Bike Photo, Bike Name

Spec Select Custom

ETRTO	Tire Size	L(mm)
23-622	700x23C	2096






RIDESYNC ARS

- Manual -


HOW TO PAIR SENSOR



RIDESYNC ARS

- Manual -


HOW TO PAIR SENSOR



RIDESYNC ARS

- Manual -

HOW TO PAIR SENSOR



RIDESYNC ARS

- Manual -

HOW TO PAIR SENSOR




or




RIDESYNC ARS

- Manual -

HOW TO PAIR SENSOR





O.K



ridesync



ALARM SYSTEM

QUICK START

START WITH RIDESYNC APP COMPUTER FUNCTION

MANU




**ALARM SYSTEM
QUICK START**

RIDESYNC ARS

- Manual -


ALARM SYSTEM





RIDESYNC ARS

- Manual -

ALARM SYSTEM









RIDESYNC ARS

- Manual -

ALARM SYSTEM







RIDESYNC ARS

- Manual -

ALARM SYSTEM






RIDESYNC ARS

- Manual -


ALARM SYSTEM



RIDESYNC ARS

- Manual -

ALARM SYSTEM






ALARM SYSTEM

**START WITH RIDESYNC APP
COMPUTER FUNCTION**

RIDESYNC ARS

- Manual -


ALARM SYSTEM



RIDESYNC ARS

- Manual -


ALARM SYSTEM



RIDESYNC ARS

- Manual -


ALARM SYSTEM



RIDESYNC ARS

- Manual -





ALARM SYSTEM



RIDESYNC ARS

- Manual -


ALARM SYSTEM




RIDESYNC ARS

- Manual -

ALARM SYSTEM






RIDESYNC ARS

- Manual -


ALARM SYSTEM



RIDESYNC ARS

- Manual -

ALARM SYSTEM






ACCIDENT SYSTEM

RIDESYNC ARS

- Manual -


ACCIDENT SYSTEM





RIDESYNC ARS

- Manual -

ACCIDENT SYSTEM








RIDESYNC ARS

- Manual -


ACCIDENT SYSTEM



RIDESYNC ARS

- Manual -

ACCIDENT SYSTEM



SOS content >

Email >

Phone Setting >

1.


2.

3.


1.

The screenshot displays a mobile application interface for an accident system. At the top, a blue header bar contains a back arrow on the left, the text "Ride Sense.r1 BAA2N314" in the center, and an "OK" button on the right. The "OK" button is highlighted with a red square, and a white hand icon with a black outline is pointing at it. Below the header, there is a grey bar with the text "SOS content" and a pencil icon. The main area of the screen is a large white rectangular field, currently empty, intended for entering the SOS content.

2.



2.




3.

The screenshot displays a mobile application interface for 'Ride Sense.r1 BAA2N314'. At the top, there is a status bar with the text '正在儲存螢幕截圖...' and a navigation bar with a back arrow, the title 'Ride Sense.r1 BAA2N314', and an 'OK' button. Below the navigation bar is a header section labeled 'Recipient' with a plus sign and an information icon. The main content area features a white dialog box with the text 'Please input phone number of the recipient.' and an empty input field. A black pencil icon is positioned over the input field. To the right of the input field is a red-bordered 'OK' button, which is being pointed to by a white hand icon.

RIDESYNC ARS

- Manual -


ACCIDENT SYSTEM



RIDESYNC ARS

- Manual -





ACCIDENT SYSTEM



RIDESYNC ARS

- Manual -


ACCIDENT SYSTEM




RIDESYNC ARS

- Manual -

ACCIDENT SYSTEM




or



RIDESYNC ARS


- Manual -

ACCIDENT SYSTEM



RIDESYNC ARS

- Manual -



ACCIDENT SYSTEM



IOS



ridesync



EN

- Manual -

JP

- マニュアル -

简体中文

- 操作手冊 -

繁體中文

- 操作手冊 -



GIANT

ridesync



HOW TO PAIR SENSOR

ALARM SYSTEM

ACCIDENT SYSTEM

Please download & install **Giant RideSync App** to your smartphone.






HOW TO PAIR SENSOR

RIDESYNC ARS

- Manual -


HOW TO PAIR SENSOR



RIDESYNC ARS

- Manual -


HOW TO PAIR SENSOR



RIDESYNC ARS

- Manual -

HOW TO PAIR SENSOR






RIDESYNC ARS

- Manual -


HOW TO PAIR SENSOR



RIDESYNC ARS

- Manual -


HOW TO PAIR SENSOR



RIDESYNC ARS

- Manual -


HOW TO PAIR SENSOR



RIDESYNC ARS

- Manual -

HOW TO PAIR SENSOR



RIDESYNC ARS

- Manual -

HOW TO PAIR SENSOR



or



RIDESYNC ARS

- Manual -


HOW TO PAIR SENSOR



RIDESYNC ARS

- Manual -

HOW TO PAIR SENSOR



O.K

MANU



ridesync



ALARM SYSTEM

QUICK START

START WITH RIDESYNC APP COMPUTER FUNCTION

MANU




**ALARM SYSTEM
QUICK START**

RIDESYNC ARS

- Manual -


ALARM SYSTEM





RIDESYNC ARS

- Manual -

ALARM SYSTEM








RIDESYNC ARS

- Manual -


ALARM SYSTEM



RIDESYNC ARS

- Manual -


ALARM SYSTEM




RIDESYNC ARS

- Manual -

ALARM SYSTEM






RIDESYNC ARS

- Manual -


ALARM SYSTEM



RIDESYNC ARS

- Manual -

ALARM SYSTEM






ALARM SYSTEM

**START WITH RIDESYNC APP
COMPUTER FUNCTION**

RIDESYNC ARS

- Manual -


ALARM SYSTEM



RIDESYNC ARS

- Manual -


ALARM SYSTEM



RIDESYNC ARS

- Manual -


ALARM SYSTEM



RIDESYNC ARS

- Manual -





ALARM SYSTEM



RIDESYNC ARS

- Manual -


ALARM SYSTEM




RIDESYNC ARS

- Manual -

ALARM SYSTEM






RIDESYNC ARS

- Manual -


ALARM SYSTEM



RIDESYNC ARS

- Manual -

ALARM SYSTEM






ACCIDENT SYSTEM

RIDESYNC ARS

- Manual -


ACCIDENT SYSTEM




RIDESYNC ARS

- Manual -

ACCIDENT SYSTEM





RIDESYNC ARS

- Manual -

ACCIDENT SYSTEM



RIDESYNC ARS

- Manual -

ACCIDENT SYSTEM



無 SIM 卡 17:21 100%

< Ride Sense.r1 BAA2N314 Save

SOS mail contents

Example SOS

Recipient +


EddieWang@xxmail.com

The screenshot shows a mobile application interface. At the top, there is a status bar with '無 SIM 卡', '17:21', and '100%' battery. Below that is a blue header bar with a back arrow, the text 'Ride Sense.r1 BAA2N314', and a 'Save' button. The main content area is titled 'SOS mail contents' and contains a large text input field with the placeholder text 'Example SOS'. Below this is a 'Recipient' field with a plus sign to its right, containing the email address 'EddieWang@xxmail.com'. A hand icon is pointing to the 'Save' button, and red boxes highlight the 'Save' button, the 'Example SOS' text field, and the 'EddieWang@xxmail.com' text field. A pencil icon is positioned over the 'Example SOS' field and the 'EddieWang@xxmail.com' field.

RIDESYNC ARS

- Manual -





ACCIDENT SYSTEM



RIDESYNC ARS

- Manual -


ACCIDENT SYSTEM




RIDESYNC ARS

- Manual -

ACCIDENT SYSTEM




or



RIDESYNC ARS

- Manual -


ACCIDENT SYSTEM



RIDESYNC ARS

- Manual -

ACCIDENT SYSTEM





ridesync



ペアリングの方法

アラームシステム


事故システム

Giant RideSync Appをダウンロードして、
スマートフォンにインストールしてください





ペアリングの方法





RIDESYNC ARS

- Manual -

ペアリングの方法

11:15

バイクの追加 **確定**


バイクデータ

 GIANT TCR

車種の写真を編集、バイク名

スペックの選択 カスタム

ETRTO	タイヤサイズ	L(mm)
23-622	700x23C	2096










RIDESYNC ARS

- Manual -

ペアリングの方法







RIDESYNC ARS

- Manual -

ペアリングの方法




or



RIDESYNC ARS

- Manual -

ペアリングの方法





O.K

ridesync



アラームシステム

クイックスタート

RideSync APP 走行中スタート

MANU




アラームシステム
クイックスタート

RIDESYNC ARS


- Manual -

アラームシステム











RIDESYNC ARS


- Manual -

アラームシステム












RIDESYNC ARS

- Manual -

アラームシステム





アラームシステム

RideSync APP

走行中スタート




RIDESYNC ARS

- Manual -

アラームシステム





RIDESYNC ARS

- Manual -



アラームシステム




RIDESYNC ARS

- Manual -

アラームシステム









RIDESYNC ARS

- Manual -

アラームシステム






事故システム


RIDESYNC ARS

- Manual -

事故システム








51B/s
0B/s

H+
11:20

< Ride Sense.r1 BAA2N314 保存

ペアリングコ... 130280CF04C9D289 

接続状態 接続済み


ファームウェアバージョン A1.0.r11

バッテリー残量 100 %


アラーム設定 >

転倒アラームの設定 >

機能テスト >







1.

The screenshot shows a mobile application interface. At the top, there is a blue header bar with a white back arrow on the left, the text 'Ride Sense.r1 BAA2N314' in the center, and a white button labeled '確定' (Determine) on the right. The '確定' button is highlighted with a red rectangular box, and a white hand cursor is pointing at it. Below the header bar, the text '救助メールの内容' (Content of rescue email) is displayed. The main area of the screen is a large white rectangle containing a black pencil icon, indicating a text input field.

2.

0B/s
0B/s H+ 11:21


< Ride Sense,r1 BAA2N314 確定

メールの通報先 +

通報先のEメールアドレスを入力してください

確定

2.



3.


正在儲存螢幕截圖...

< Ride Sense.r1 BAA2N314 確定

メールの通報先 + ⓘ

受信者の入力電話番号をお願いします

確定









RIDESYNC ARS

- Manual -

事故システム







RIDESYNC ARS

- Manual -

事故システム



or



RIDESYNC ARS

- Manual -

事故システム



RIDESYNC ARS

- Manual -

事故システム



GIANT

ridesync



ペアリングの方法

アラームシステム

事故システム

Giant RideSync Appをダウンロードして、
スマートフォンにインストールしてください





ペアリングの方法

RIDESYNC ARS

- Manual -

ペアリングの方法






RIDESYNC ARS

- Manual -

ペアリングの方法








RIDESYNC ARS

- Manual -

ペアリングの方法






RIDESYNC ARS

- Manual -


ペアリングの方法



RIDESYNC ARS

- Manual -

ペアリングの方法




or



RIDESYNC ARS

- Manual -

ペアリングの方法



RIDESYNC ARS

- Manual -

ペアリングの方法



O.K

MANU

GIANT

ridesync



アラームシステム

クイックスタート

RideSync APP走行中スタート

MANU




アラームシステム
クイックスタート

RIDESYNC ARS


- Manual -

アラームシステム










RIDESYNC ARS


- Manual -

アラームシステム









RIDESYNC ARS

- Manual -

アラームシステム



RIDESYNC ARS

- Manual -

アラームシステム





アラームシステム

RideSync APP

走行中スタート

RIDESYNC ARS

- Manual -


アラームシステム




RIDESYNC ARS

- Manual -

アラームシステム





RIDESYNC ARS

- Manual -



アラームシステム



RIDESYNC ARS

- Manual -

アラームシステム




RIDESYNC ARS

- Manual -

アラームシステム







RIDESYNC ARS

- Manual -

アラームシステム






事故システム

RIDESYNC ARS

- Manual -


事故システム











The screenshot shows the mobile app interface for reporting an accident. At the top, the status bar displays '無 SIM 卡', '17:40', and '100%' battery. The app header shows a back arrow, the text 'Ride Sense.r1 BAA2N314', and a '保存' (Save) button highlighted with a red box. Below the header, the section '救助メールの内容' (Content of rescue email) contains a text input field with 'Example SOS' and a pencil icon. Below this, the section 'メールの通報先' (Email notification recipient) has a text input field containing 'EddieWang@xxmail.com' and a plus sign icon. Both input fields are highlighted with red boxes. A hand icon is pointing at the '保存' button.



RIDESYNC ARS

- Manual -

事故システム




選択


乗車開始

記録停止





GIANT TCR
700x30C





or






RIDESYNC ARS

- Manual -

事故システム



GIANT

ridesync



如何配对ARS装置

警报系统

意外通知系统

请先下载并安装Giant RideSync App至您的智慧型手机






如何配对ARIS装置

RIDESYNC ARS

- Manual -

如何配对ARS装置



RIDESYNC ARS

- Manual -

如何配对ARS装置



RIDESYNC ARS

- Manual -

如何配对ARS装置



新增爱车

确定

基本资料

 GIANT TCR

编辑车种照片、爱车名称

规格选取 自订

ETRTO	轮胎尺寸	L(mm)
23-622	700x23C	2096

RIDESYNC ARS

- Manual -

如何配对ARS装置



RIDESYNC ARS

- Manual -


如何配对ARS装置



RIDESYNC ARS

- Manual -


如何配对ARS装置



RIDESYNC ARS

- Manual -

如何配对ARS装置



RIDESYNC ARS

- Manual -

如何配对ARS装置



RIDESYNC ARS

- Manual -

如何配对ARS装置




或



RIDESYNC ARS

- Manual -

如何配对ARS装置



RIDESYNC ARS

- Manual -

如何配对ARS装置



O.K

主选单



ridesync



警报系统

快速启动

RideSync APP 骑乘中启动

主选单




警报系统

快速启动


RIDESYNC ARS

- Manual -

警报系统










RIDESYNC ARS

- Manual -

警报系统







RIDESYNC ARS

- Manual -

警报系统



RIDESYNC ARS

- Manual -

警报系统





警报系统

RideSync APP

骑乘中启动

RIDESYNC ARS

- Manual -


警报系统




RIDESYNC ARS

- Manual -

警报系统







RIDESYNC ARS

- Manual -

警报系统






RIDESYNC ARS

- Manual -

警报系统





RIDESYNC ARS

- Manual -

警报系统



RIDESYNC ARS

- Manual -

警报系统





意外通知系统

RIDESYNC ARS

- Manual -

意外通知系统





RIDESYNC ARS

- Manual -

意外通知系统








RIDESYNC ARS

- Manual -

意外通知系统






1.

The screenshot displays a mobile application interface. At the top, a blue header bar contains a back arrow on the left, the text 'Ride Sense.r1 BAA2N314' in the center, and a '确定' (Confirm) button on the right. The '确定' button is highlighted with a red rectangular box, and a white hand cursor icon is pointing at it. Below the header, the text '求救信内容' (Emergency Message Content) is displayed. Underneath this text is a large white rectangular area containing a black pencil icon, indicating a text input field. The rest of the screen is blank white space.


2.



2.



3.





RIDESYNC ARS

- Manual -


意外通知系统



RIDESYNC ARS

- Manual -


意外通知系统



RIDESYNC ARS

- Manual -


意外通知系统




RIDESYNC ARS

- Manual -

意外通知系统



or



RIDESYNC ARS

- Manual -

意外通知系统



RIDESYNC ARS

- Manual -



意外通知系统



IOS



ridesync



如何配对ARS装置

警报系统

意外通知系统

请先下载并安装Giant RideSync App至您的智慧型手机





如何配对ARS装置

RIDESYNC ARS

- Manual -

如何配对ARS装置



RIDESYNC ARS

- Manual -

如何配对ARS装置



RIDESYNC ARS

- Manual -

如何配对ARS装置



無 SIM 卡 14:53 86%

< 新增爱车 确定

基本资料

 GIANT TCR

编辑车种照片、爱车名称

规格选取 自订

ETRTO	轮胎尺寸	轮胎周长
23-622	700x23C	2096



RIDESYNC ARS

- Manual -


如何配对ARS装置



RIDESYNC ARS

- Manual -


如何配对ARS装置



RIDESYNC ARS

- Manual -


如何配对ARS装置



RIDESYNC ARS

- Manual -

如何配对ARS装置



RIDESYNC ARS

- Manual -

如何配对ARS装置



或



RIDESYNC ARS

- Manual -

如何配对ARS装置



RIDESYNC ARS

- Manual -

如何配对ARS装置



主选单



ridesync



警报系统

快速启动

RideSync APP 骑乘中启动

主选单



警报系统

快速启动

RIDESYNC ARS


- Manual -

警报系统









RIDESYNC ARS


- Manual -

警报系统











RIDESYNC ARS

- Manual -

警报系统





警报系统

RideSync APP

骑乘中启动

RIDESYNC ARS

- Manual -

警报系统




RIDESYNC ARS

- Manual -

警报系统







RIDESYNC ARS


- Manual -

警报系统









RIDESYNC ARS

- Manual -

警报系统



RIDESYNC ARS

- Manual -

警报系统





意外通知系统


RIDESYNC ARS

- Manual -

意外通知系统







RIDESYNC ARS

- Manual -

意外通知系统





無 SIM 卡 15:38 92%

< Ride Sense.r1 BAA2N314 储存

求救信内容

Example SOS

发信对象 +

hank@program.com.tw

RIDESYNC ARS

- Manual -


意外通知系统



RIDESYNC ARS

- Manual -


意外通知系统




RIDESYNC ARS

- Manual -

意外通知系统



or



RIDESYNC ARS

- Manual -

意外通知系统



RIDESYNC ARS

- Manual -

意外通知系统





ridesync



如何配對ARS裝置

警報系統

意外通知系統

請先下載並安裝Giant RideSync App至您的智慧型手機





如何配對ARS裝置

RIDESYNC ARS

- Manual -

如何配對ARS裝置



RIDESYNC ARS

- Manual -

如何配對ARS裝置



RIDESYNC ARS

- Manual -

如何配對ARS裝置



新增愛車

確定

基本資料

 GIANT TCR

編輯車種照片、愛車名稱

規格選取 自訂

ETRTO	輪胎尺寸	L(mm)
23-622	700x23C	2096

RIDESYNC ARS

- Manual -

如何配對ARS裝置



RIDESYNC ARS

- Manual -


如何配對ARS裝置



RIDESYNC ARS

- Manual -


如何配對ARS裝置



RIDESYNC ARS

- Manual -


如何配對ARS裝置



RIDESYNC ARS

- Manual -

如何配對ARS裝置



RIDESYNC ARS

- Manual -

如何配對ARS裝置




或



RIDESYNC ARS

- Manual -


如何配對ARS裝置



RIDESYNC ARS

- Manual -

如何配對ARS裝置



O.K

主選單



ridesync



警報系統

快速啟動

RideSync APP 騎乘中啟動

主選單



警報系統

快速啟動


RIDESYNC ARS

- Manual -

警報系統








RIDESYNC ARS

- Manual -


警報系統




RIDESYNC ARS

- Manual -

警報系統







RIDESYNC ARS

- Manual -

警報系統



RIDESYNC ARS

- Manual -

警報系統





警報系統

RideSync APP


騎乘中啟動




RIDESYNC ARS

- Manual -

警報系統







RIDESYNC ARS

- Manual -

警報系統






RIDESYNC ARS

- Manual -

警報系統





RIDESYNC ARS

- Manual -

警報系統



RIDESYNC ARS

- Manual -

警報系統






意外通知系統

RIDESYNC ARS

- Manual -

意外通知系統




RIDESYNC ARS

- Manual -

意外通知系統








RIDESYNC ARS

- Manual -

意外通知系統






1.



2.



2.



3.


正在儲存螢幕截圖...

< Ride Sense.r1 BAA2N314 確定

發信對象 + ⓘ

請輸入發信對象的手機號碼

確定





RIDESYNC ARS

- Manual -

意外通知系統



RIDESYNC ARS

- Manual -


意外通知系統



RIDESYNC ARS

- Manual -


意外通知系統




RIDESYNC ARS

- Manual -

意外通知系統



or



RIDESYNC ARS

- Manual -

意外通知系統



RIDESYNC ARS

- Manual -

意外通知系統



主选单

IOS

GIANT

ridesync



如何配對ARS裝置

警報系統

意外通知系統

請先下載並安裝Giant RideSync App至您的智慧型手機





如何配對ARS裝置

RIDESYNC ARS

- Manual -

如何配對ARS裝置



RIDESYNC ARS

- Manual -

如何配對ARS裝置



RIDESYNC ARS

- Manual -

如何配對ARS裝置



無 SIM 卡 14:41 89%

< 新增愛車 確定

基本資料

 GIANT TCR

編輯車種照片、愛車名稱

規格選取 自訂

ETRTO	輪胎尺寸	輪胎周長
23-622	700x23C	2096

RIDESYNC ARS

- Manual -

如何配對ARS裝置



RIDESYNC ARS

- Manual -


如何配對ARS裝置



RIDESYNC ARS

- Manual -


如何配對ARS裝置



RIDESYNC ARS

- Manual -

如何配對ARS裝置



RIDESYNC ARS

- Manual -

如何配對ARS裝置



RIDESYNC ARS

- Manual -

如何配對ARS裝置



或



RIDESYNC ARS

- Manual -

如何配對ARS裝置



RIDESYNC ARS

- Manual -

如何配對ARS裝置



主選單



ridesync



警報系統

快速啟動

RideSync APP 騎乘中啟動

主選單



警報系統

快速啟動

RIDESYNC ARS

- Manual -

警報系統




RIDESYNC ARS

- Manual -

警報系統







RIDESYNC ARS


- Manual -

警報系統









RIDESYNC ARS

- Manual -

警報系統



RIDESYNC ARS

- Manual -

警報系統





警報系統

RideSync APP

騎乘中啟動

RIDESYNC ARS

- Manual -

警報系統




RIDESYNC ARS

- Manual -

警報系統





RIDESYNC ARS

- Manual -



警報系統




RIDESYNC ARS

- Manual -

警報系統





RIDESYNC ARS

- Manual -

警報系統





意外通知系統

RIDESYNC ARS

- Manual -

意外通知系統



RIDESYNC ARS

- Manual -

意外通知系統





RIDESYNC ARS

- Manual -

意外通知系統



RIDESYNC ARS

- Manual -

意外通知系統



The screenshot shows a mobile application interface for sending an emergency notification. At the top, the status bar displays '無 SIM 卡', '14:47', and '87%' battery. The app header shows a back arrow, the text 'Ride Sense.r1 BAA2N314', and a '儲存' (Save) button highlighted with a red box. A hand icon is pointing at this button. Below the header is a section labeled '求救信內容' (Emergency Message Content) with a pencil icon. A large red rectangular box highlights the text input area, which contains the text 'Example SOS!'. Below this is a section labeled '發信對象' (Recipient) with a plus sign icon. A red rectangular box highlights the input field containing the email address 'hank@program.com.tw'. Below the recipient field are several empty horizontal lines for additional recipients.

RIDESYNC ARS

- Manual -



意外通知系統



RIDESYNC ARS

- Manual -


意外通知系統




RIDESYNC ARS

- Manual -

意外通知系統



or



RIDESYNC ARS

- Manual -

意外通知系統



RIDESYNC ARS

- Manual -

意外通知系統



主選單